

Exhaust Monitoring System Instruction Manual



Table of Contents

Installation
Home Screen
Settings
Screen Saver
High Temperature Alarm7
High Temperature Warning8
Building Alarm Tie-in
Run Blower Continuously
Blower Run Interval
Blower Run Time to Sample
Keep Blower Running if Ambient Air plus X degrees
Reset Blower if Ambient Air plus X degrees
Alarm Volume
Sensor Type
Thermocouple Assignments17
Maintenance
Smoke Alarm Cleaning

1. Place the monitoring system on the cabinet, aligning the intake and exhaust ports at the top of the cabinet.



2. Connect the system power cord and allow the screen to warm up, the exhaust fan will run for a short period of time.

EMS

EMS PLUS ONLY



Shelf-Level Thermal Monitoring. [See page 16]



Home Screen



1. Temp Sensors

EMS: Select to display the temperature of the cabinet.

EMS Plus: Select to display the temperature at each thermocouple location.

2. Silence Alarm

Silences the audible alarm until system is reset. Turn module off and back on again to reset the audible alarm.

3. Test Buzzer

Select to test the audible alarm.

4. Test Strobe

Select to test visual strobe alarm.

5. Settings

Opens the settings menu. See pages 5 - 13 for detailed settings options.

6. Ambient

Displays external temperature of the air surrounding the cabinet.

7. Cabinet

EMS: Displays internal temperature of cabinet at the vent.

EMS Plus: Displays highest temperature within the cabinet independent of location.

Setti	ngs Screen	Set	tings								
		Scree	en Saver		Ye	S		\bigcap	-	2	
	High	Temp (Deg	erature Ala Jrees F)	arm	1	60.0					
	High 1	Tempe (Deg	rature War Jrees F)	rning	1	25.0					
	Alar	m rela alarm	y state wh present	en		osed					
	Ba	ck			Prev	Ne	ext				
)			(3					

1. Back

Returns to home screen

2. Vertical Scroll and 3. Prev/Next

Access additional settings by scrolling **OR**

Access additional menu items by using the Previous and Next buttons

Screen Saver



High Temperature Alarm



Description:

This is the internal cabinet temperature threshold required to deploy the audible alarm and red strobe light. This setting will also indicate what temperature will deactivate the exhaust fan to prevent an accelerated thermal runaway.

Access From: Settings Screen

Settings

Preset Value: 160° F

- 1. Select the temperature setting to open the next screen.
- 2. Press **Cir** to delete the previous setting.
- 3. Input the new temperature limit in degrees Fahrenheit.
- 4. Press Enter to return to settings screen



High Temperature Warning



Description:

The internal cabinet temperature threshold required to set off the yellow strobe light. The blower remains on.

Access From: Settings Screen

Settings

Preset Value: 125° F

- 1. Select the temperature setting to open the next screen.
- 2. Press **Cir** to delete the previous setting.
- 3. Input the new temperature limit in degrees Fahrenheit.
- 4. Press Enter to return to settings screen



Building Alarm Tie-in – EMS Plus Only



Wiring:

Pin 1: Relay 1 – Alarm Relay
Pin 2: Relay 1 – Alarm Relay
Pin 3: Relay 2 – Warning Relay (if applicable)
Pin 4: Relay 2 – Warning Relay (if applicable)

Note on EOL Resistor Installation

Removing the small top screw on the connector housing allows the contact insert to be removed. This provides access for customers who wish to install their own EOL (End of Line) resistors.

Please note that we do not provide instructions for EOL resistor implementation, as it varies based on each customer's specific alarm system and wiring configuration. Installer should consult their internal technical team or their fire/building alarm vendor for guidance on proper integration.

Alarm Relay State – EMS Plus Only



Toggle the selection button to match the connected circuit system. Select **Closed** for a closed alarm circuit system or **Open** for an open alarm system.

Warning Relay State – EMS Plus Only



Toggle the selection button to match the connected circuit system. Select **Closed** for a closed alarm circuit system or **Open** for an open alarm system.

Note: Removing the power does NOT change the state of either relay. Each will remain in it's last state upon loss of power. In other words, if in alarm, turning off the power will not change the condition of the relay contacts.

Run Blower Continuously



Toggle the selection button to set.

- 1. When set to **On** blower will run continuously, independent of temperature.
- 2. When set to **Off** blower will only run on the user-programmed intervals.

Blower Run Interval



Description:

The period in minutes the module waits between running the blower to record a sample temperature of inside the cabinet.

Access From: Settings Screen

Settings

Preset Value: 8 (minutes)

- 1. Select the interval setting to access the next screen
- 2. Press **Cir** to delete the previous setting
- 3. Input the new time interval in minutes
- 4. Press Enter to return to settings screen



Blower Run Time to Sample



Description:

The period in seconds the blower will draw air during each Sample Temperature Interval.

Access From: Settings Screen

Settings

Preset Value: 120 (seconds)

- 1. Select the run time setting to access the next screen
- 2. Press **Cir** to delete the previous setting
- 3. Input the new time interval in seconds
- 4. Press Enter to return to settings screen



CellBlock[®]

Keep Blower Running if Ambient Air plus X degrees



Description:

The temperature difference between the internal cabinet temperature and external ambient temperature. Exceeding this threshold will trigger the blower to run constantly. Used in instances when battery chargers increase the internal temperature of the cabinet without thermal runaway occurring.

Access From: Settings Screen

Settings

Preset Value: 10° F

- 1. Select the run time setting to access the next screen
- 2. Press **Cir** to delete the previous setting
- 3. Input the new temperature difference in degrees Fahrenheit.
- 4. Press Enter to return to settings screen



Reset Blower if Ambient Air plus X degrees



Description:

The temperature difference between the internal cabinet temperature and external ambient temperature which will reset the exhaust fan to previous settings once the cabinet has decreased in temperature from the **Keep Blower Running if Ambient Air plus X degrees** occurrence.

Access From: Settings Screen

Settings

Preset Value: 5° F

- 1. Select the run time setting to access the next screen
- 2. Press **Cir** to delete the previous setting
- 3. Input the new temperature difference in degrees Fahrenheit.
- 4. Press Enter to return to settings screen



Alarm Volume



Preset Value: 5

- 1. Select the Alarm Volume setting to access the next screen
- 2. Press **CIr** to delete the previous setting
- 3. Enter a value from 1 to 10 to set the alarm volume in 10 dB increments (1 = 10 dB, 10 = **100 dB maximum**).
- 4. Press Enter to return to settings screen



Sensor Type



Description:

Sensor Type syncs the system with the correct thermocouple type. Options include B, E, J, K, N, R, S, and T. **If none are selected the device will not alarm for temperature.** (CellBlock FCS installs K-Type thermocouples).

NOTE:

EMS: Only Sensor 1 is used. If using the pre-installed sensor, select K-Type. **EMS+:** Sensors 1-6 will be used.

EMS+: Sensors 1-12 will be used. Additional sensors by special orders only. See Chart on page 15 for TC assignments

Access From: Settings Screen

Settings

Preset Value: K-Type

- 1. Select the Sensor Type setting to access the next screen
- 2. Select Sensor Type from menu
- 4. Press Enter to return to settings screen



CellBlock[®]

	ALL Cabinets Standard EMS	3672/6172 EMS+ (5 Shelves)	3672/6172 EMS++ (5 Shelves)	6165 EMS+ (4 Shelves)	6165 EMS++ (4 Shelves)	1952 EMS+ (3 shelves)	1952 EMS++ (3 shelves)	3736 EMS+ (2 shelves)
TC1	Exhaust	Exhaust	Exhaust	Exhaust	Exhaust	Exhaust	Exhaust	Exhaust
TC2	none	Shelf 1	Shelf 1A	Shelf 1	Shelf 1A	Shelf 1	Shelf 1A	Shelf 1A
TC3	none	Shelf 2	Shelf 1B	Shelf 2	Shelf 1B	Shelf 2	Shelf 1B	Shelf 1B
TC4	none	Shelf 3	Shelf 2A	Shelf 3	Shelf 2A	Shelf 3	Shelf 2A	Shelf 2A
TC5	none	Shelf 4	Shelf 2B	Shelf 4	Shelf 2B	none	Shelf 2B	Shelf 2B
TC6	none	Shelf 5	Shelf 3A	none	Shelf 3A	none	Shelf 3A	none
TC7	none	none	Shelf 3B	none	Shelf 3B	none	Shelf 3B	none
TC8	none	none	Shelf 4A	none	Shelf 4A	none	none	none
TC9	none	none	Shelf 4B	none	Shelf 4B	none	none	none
TC10	none	none	Shelf 5A	none	none	none	none	none
TC11	none	none	Shelf 5B	none	none	none	none	none
TC12	none	none	none	none	none	none	none	none

Smoke Alarm Cleaning

Frequency: Every 6 months.

- 1. Remove the twenty screws using a flat head screwdriver. Lift the module cover off.
- 2. Turn the removable sensor on the smoke alarm counterclockwise until it disconnects.



- 3. Carefully blow any dust or debris off the sensor and sensor housing.
- 4. To reconnect the sensor, turn clockwise until hand tight.
- 5. Place the module cover on the top and screw in using the twenty screws.