


INSTALLATION



1x - Wall-mount Plate




2x - Sheet Rock Anchors




2x - Mounting Screws

The High Watt Hour EHS Kit is safety equipment. Install the wall-mount plate in a prominent spot at eye-level for quick access. Pre-drilling holes is recommended. Sheet rock anchors are provided if a solid wall support is not available.

Once the wall plate is installed, the High Watt Hour EHS Kit may be hung by sliding the mounting strap over the tongue of the wall-mount plate.



FRONT





BACK

Mounting Strap

RECOMMENDED USE (High Watt Hour Kit Shown)

LITHIUM BATTERY FIRE? SMOKE? OVERHEATING?


Access the fire-suppression tools within your High Watt Hour EHS Kit by grasping the front handle and lifting the front flap.



*High watt hour kit only




Put on Gloves and Goggles.*




Unfold FireShield Blanket and use as a shield to approach the battery.

Keep blanket between you and the battery.



Place PED-Pad over battery or device



Place FireShield Blanket over the PED-Pad. Allow PED-Pad to extinguish.

Follow your emergency procedures.

*Goggles included in High watt hour kit only



SCAN ME!
for more info and best practices